







⚠ 搭建时请尽量安装防护罩(飞行器除外), 以免运行时划伤。

Please install the protective covers as far as possible when assembling (except for aircraft).






更多扩展
Create more



马戏小丑 Circus Clown










有节奏的控制动力模块,能让木偶倾斜和摆动,可以像马戏小丑一样摇摆走路、旋转或跳舞。

Rhythmic control power module that allows puppets to tilt and swing, dance or dance like a circus clown.



组装说明 Assembly Instructions

1-1



makeblock

Makeblock Co., Ltd. | Tel: +86(0)755-26392228 | www.makeblock.com | Email: info@makeblock.com



@makeblock



@makeblock



@makeblock



@makeblock



himakeblock

CHOKING HAZARD

Small parts. Not for children under 3 years.
Children to use only under adult's supervision.

内含细小零件可能引起窒息风险, 不适宜3岁以下儿童使用。
儿童需要在成人陪同下使用。使用年龄: 8岁以上。



最终解释权归Makeblock所有

@2017 Makeblock Co., Ltd. All rights reserved. This English version Limited Warranty is only for reference, and it is subject to the Chinese version Limited Warranty.